



PARTS DESCRIPTION BREAKDOWN FOR STARTER KITS

PART DESCRIPTION		PART #	#	PART #	#	PART #	#
		5-52001 4 TON	Needed	5-52011 10 TON	Needed	5-52029 20 Ton	Needed
Clamp (Offset) Head (one)	A	13-11620		13-11621			
90° Concave "V" Base	B	13-11626	2	13-11651			
Flat Base	C	13-11625		13-11623			
3" Rubber Head Assembly	D	4-50577		4-50578			
3" Rubber Head Only NOT SHOWN		13-11639		13-11639			
Male Connector	E	10-11644		13-11656			
Chain & Hook	F	10-11694	2	19-11668	2	4-59434	2
Chain Pull Plate	G	13-11627		13-11622		4-59427	
Wedge Head	I	13-11617		13-11652			
Plunger Toe	J	13-11618		13-11649			
Body Toe	K	13-11619		13-11654			
18" Extension Tube	L	13-11633		13-11660			
15 " Extension Tube	M	13-11632	3	13-11659			
12" Extension Tube	AC			13-11658			
10" Extension Tube	N					4-59442	2
6" Extension Tube	O	13-11630		13-11657			
3" Extension Tube	P	13-11629					
24" Extension Tube	Q					4-59438	
20" Extension Tube	R					4-59440	
Male Adaptor	S	13-11634		13-11661	2		
Female Adaptor	T	13-11635		13-11662			
Lock Pins	U	58451	4	56043	4		
Ext Tube Connectors	V	13-11636	3	13-11663	2		
Pump	W	5-52005		5-52015		5-52015	
Standard Ram	X	5-52006		5-52016		5-52028	
Quick Disconnect (Hose & Ram)	Z	19-11812		19-11815		19-11815	
Coupler Hose Half	AA	19-11811		19-11814		19-11814	
Coupler Ram Half	AB	19-11810		19-11813		19-11813	
Spreader Toe	AD			13-11650			
Clamp End Toe	AE			13-11653			
5" Rubber Head Assembly	AI			19-11706			
5" Rubber Head Only		NOT SHOWN		19-11704			
Hose	AG	13-11695		13-11597		13-11597	
*OPTIONAL Hyd. Mini Spreader	AH	5-52047		5-52047			
Ram Base	AJ					4-59431	
Plunger Base	AK					4-59429	
Toe Lift	AL					4-59436	
Coupling	AM					4-59435	2
Ram Caps	AN	13-11678		13-11692		2-59174	
Thread Protectors	AO	2-53329		2-53328		2-59178	
Carry Case		56168		59159		59159	